



PO Box 6256
Mobile AL, 36606
1-800-771-6643

APPLICATION DETAILS TPO Peel & Stick (HW) & (SA) Roof Systems

<p>Angle Change</p> <p>Clear Primer</p> <p>Locate and cut deck flange even with the corner.</p>	<p>Turn membrane around corner without distorting the panel.</p> <p>Clear Primer</p>	<p>Clear Primer</p>
<ol style="list-style-type: none"> 1. Install base securement at the angle change. 2. Prime vertical substrate with Clear Primer at the rate of 200 ft²/gal (4.91 m²/L). 3. Position Peel & Stick membrane (cut to fit the height of the curb by the diameter of the curb plus 6" (152.40 mm)) into the angle change and lined up with a down-slope corner of the curb. 4. Locate the corner of the curb by feel through the Peel & Stick membrane, and cut the deck flange portion of the membrane in order to wrap the Peel & Stick membrane around the corner. 	<ol style="list-style-type: none"> 5. Repeat Step 4 as required to wrap entire curb. 	<ol style="list-style-type: none"> 6. Once the Peel & Stick membrane has been wrapped around the primed curb, prime the top of the membrane panel end in preparation for the flap to be wrapped around the corner and mated to the membrane surface. In keeping with good roofing practice, the flap should be oriented on the down-slope side of the penetration.
<p>Cut the bottom of the flap at a 45 degree angle</p>		
<ol style="list-style-type: none"> 7. After the primer applied in Step 6 flashes-off, wrap the membrane flap around the corner and roll into place. 	<ol style="list-style-type: none"> 8. Fold the excess flashing onto the top of the penetration, neatly creasing the corners and fasten. 	<ol style="list-style-type: none"> 9. After seaming the flashing flange to the deck sheet, prime the corner with Clear Primer and apply a corner flashing molded from the TPO Peel & Stick flashing kit material.
	<ol style="list-style-type: none"> 10. Apply TPO Edge Caulk to the Peel & Stick TPO edges and around the corner flashing molded from the Peel & Stick Flashing Kit material. 	
<p>Peel & Stick Curb Flashing</p>	<p>Peel & Stick TPO Systems</p>	