



PO Box 6256
 Mobile AL, 36606
 1-800-771-6643

APPLICATION DETAILS TPO Peel & Stick (HW) & (SA) Roof Systems

1. Clear Primer & 6" (152.40 mm) Wide Seam

2. Clean Area with Cleaner, and Then Apply Clear Primer.

3. Clear Primer Required On All Vertical Substrates

4. Any Approved Base Flashing Detail

5. Approved Substrate ISO Peel & Stick TPO Membrane

6. Primer

7. Fold

8. TPO Flashing Kit Material

9. Clear Primer

10. TPO Flashing Kit Material

11. Clear Primer

12. TPO Flashing Kit Material

13. Apply a High Profile Bead of TPO Edge Caulk to ALL Completed Seams

- All parapet walls and roof curbs must be suitable for flashing, i.e. clean, tight, smooth, no cracks, etc. and be primed with Clear Primer.
- Polymer batten strips cannot be used for attachments into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.
- Apply TPO Edge Caulk to all seam and flashing edges.

American
WEATHERSTAR

SINGLE-PLY

0109

Inside Corner Flashing w/ TPO Flashing Kit Material	Peel & Stick TPO Systems
---	--------------------------