



PO Box 6256
Mobile AL, 36606
1-800-771-6643

APPLICATION DETAILS

TPO Peel & Stick (HW) & (SA) Roof Systems

<p>A</p>	<p>Peel & Stick TPO (SA) Seaming</p> <p>TPO Edge Sealant (Required on all "SA" seams)</p> <p>Clear Primer</p> <p>SA Seams are to be minimum 4" (101.60 mm) wide on side laps and 6" (152.40 mm) wide on end laps.</p>
<p>B</p>	<p>Peel & Stick TPO (HW) & 3" White Seam Tape</p> <p>TPO Edge Sealant (Required on all seam tape seams)</p> <p>Clear Primer</p> <p>3" White Seam Tape</p> <p>Position the upper membrane panel as required to achieve a 3" lap over the adjacent panel and mark the position of the upper membrane panel edge plus 1/4" with a crayon on the lower panel, prime the seaming areas of both panels and allow the primer to flash off, then position and apply the 3" White Seam Tape along the marks as required to achieve 1/8" to 1/4" of exposure once the seam is assembled.</p>
<p>C</p>	<p>Peel & Stick TPO (HW) & Hot Air Welded Seams</p> <p>1 1/2" min. (38.10 mm) Hot Air Weld</p>
<p>Seaming Methods for Peel & Stick TPO</p>	<p>Peel & Stick TPO Systems</p>

